

Cogged (REC) V-Belts



Finer Power Transmissions P/L | www.finerpt.com

BOOK 2: BELTS & PULLEYS CONTENTS

2.1 V-BELTS CONTENTS

| AX SECTION | | | | | | | | | | | |
|-------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|--------|
| AX-20 | AX-27 | AX-34 | AX-41 | AX-48 | AX-55 | AX-62 | AX-69 | AX-76 | AX-83 | AX-90 | AX-97 |
| AX-21 | AX-28 | AX-35 | AX-42 | AX-49 | AX-56 | AX-63 | AX-70 | AX-77 | AX-84 | AX-91 | AX-98 |
| AX-22 | AX-29 | AX-36 | AX-43 | AX-50 | AX-57 | AX-64 | AX-71 | AX-78 | AX-85 | AX-92 | AX-99 |
| AX-23 | AX-30 | AX-37 | AX-44 | AX-51 | AX-58 | AX-65 | AX-72 | AX-79 | AX-86 | AX-93 | AX-100 |
| AX-24 | AX-31 | AX-38 | AX-45 | AX-52 | AX-59 | AX-66 | AX-73 | AX-80 | AX-87 | AX-94 | AX-105 |
| AX-25 | AX-32 | AX-39 | AX-46 | AX-53 | AX-60 | AX-67 | AX-74 | AX-81 | AX-88 | AX-95 | AX-136 |
| AX-26 | AX-33 | AX-40 | AX-47 | AX-54 | AX-61 | AX-68 | AX-75 | AX-82 | AX-89 | AX-96 | AX-144 |
| BX SECTION | | | | | | | | | | | |
| BX-24 | BX-32 | BX-40 | BX-48 | BX-56 | BX-64 | BX-72 | BX-80 | BX-88 | BX-96 | BX-112 | |
| BX-25 | BX-33 | BX-41 | BX-49 | BX-57 | BX-65 | BX-73 | BX-81 | BX-89 | BX-97 | BX-115 | |
| BX-26 | BX-34 | BX-42 | BX-50 | BX-58 | BX-66 | BX-74 | BX-82 | BX-90 | BX-98 | BX-118 | |
| BX-27 | BX-35 | BX-43 | BX-51 | BX-59 | BX-67 | BX-75 | BX-83 | BX-91 | BX-99 | BX-120 | |
| BX-28 | BX-36 | BX-44 | BX-52 | BX-60 | BX-68 | BX-76 | BX-84 | BX-92 | BX-100 | BX-124 | |
| BX-29 | BX-37 | BX-45 | BX-53 | BX-61 | BX-69 | BX-77 | BX-85 | BX-93 | BX-103 | BX-133 | |
| BX-30 | BX-38 | BX-46 | BX-54 | BX-62 | BX-70 | BX-78 | BX-86 | BX-94 | BX-105 | BX-144 | |
| BX-31 | BX-39 | BX-47 | BX-55 | BX-63 | BX-71 | BX-79 | BX-87 | BX-95 | BX-108 | BX-180 | |
| CX SECTION | | | | | | | | | | | |
| CX-42 | CX-51 | CX-60 | CX-70 | CX-78 | CX-87 | CX-105 | CX-116 | CX-136 | CX-173 | | |
| CX-45 | CX-56 | CX-62 | CX-72 | CX-81 | CX-90 | CX-108 | CX-120 | CX-144 | CX-180 | | |
| CX-46 | CX-57 | CX-65 | CX-75 | CX-83 | CX-96 | CX-109 | CX-125 | CX-158 | | | |
| CX-48 | CX-58 | CX-68 | CX-76 | CX-85 | CX-100 | CX-110 | CX-128 | CX-166 | | | |
| XPA SECTION | | | | | | | | | | | |
| XPA-630 | XPA-925 | XPA-1090 | XPA-1232 | XPA-1400 | XPA-1600 | XPA-1900 | XPA-2240 | XPA-3000 | | | |
| XPA-800 | XPA-950 | XPA-1120 | XPA-1250 | XPA-1430 | XPA-1650 | XPA-1950 | XPA-2360 | XPA-3150 | | | |
| XPA-825 | XPA-975 | XPA-1140 | XPA-1280 | XPA-1450 | XPA-1700 | XPA-2000 | XPA-2500 | XPA-3350 | | | |
| XPA-850 | XPA-1000 | XPA-1150 | XPA-1320 | XPA-1500 | XPA-1750 | XPA-2060 | XPA-2580 | XPA-3550 | | | |
| XPA-875 | XPA-1030 | XPA-1180 | XPA-1357 | XPA-1532 | XPA-1800 | XPA-2120 | XPA-2650 | | | | |
| XPA-900 | XPA-1060 | XPA-1220 | XPA-1360 | XPA-1550 | XPA-1850 | XPA-2180 | XPA-2800 | | | | |
| XPB SECTION | | | | | | | | | | | |
| XPB-1000 | XPB-1270 | XPB-1450 | XPB-1650 | XPB-1850 | XPB-2060 | XPB-2280 | XPB-2610 | XPB-3000 | XPB-3550 | XPB-4250 | |
| XPB-1120 | XPB-1320 | XPB-1500 | XPB-1690 | XPB-1900 | XPB-2120 | XPB-2360 | XPB-2650 | XPB-3150 | XPB-3750 | XPB-4500 | |
| XPB-1180 | XPB-1340 | XPB-1550 | XPB-1700 | XPB-1950 | XPB-2150 | XPB-2410 | XPB-2680 | XPB-3170 | XPB-3800 | XPB-4750 | |
| XPB-1250 | XPB-1400 | XPB-1590 | XPB-1750 | XPB-2000 | XPB-2180 | XPB-2500 | XPB-2800 | XPB-3250 | XPB-4000 | XPB-4820 | |
| XPB-1260 | XPB-1410 | XPB-1600 | XPB-1800 | XPB-2020 | XPB-2240 | XPB-2530 | XPB-2840 | XPB-3350 | XPB-4060 | | |
| XPC SECTION | | | | | | | | | | | |
| XPC-2000 | XPC-2240 | XPC-2500 | XPC-2800 | XPC-3150 | XPC-3550 | XPC-4000 | XPC-4500 | XPC-4900 | | | |
| XPC-2120 | XPC-2360 | XPC-2650 | XPC-3000 | XPC-3350 | XPC-3750 | XPC-4250 | XPC-4750 | | | | |
| XPZ SECTION | | | | | | | | | | | |
| XPZ-610 | XPZ-760 | XPZ-875 | XPZ-980 | XPZ-1090 | XPZ-1220 | XPZ-1320 | XPZ-1470 | XPZ-1600 | XPZ-1850 | XPZ-2280 | |
| XPZ-612 | XPZ-772 | XPZ-900 | XPZ-1000 | XPZ-1120 | XPZ-1240 | XPZ-1340 | XPZ-1500 | XPZ-1637 | XPZ-1900 | XPZ-2410 | |
| XPZ-630 | XPZ-800 | XPZ-910 | XPZ-1010 | XPZ-1140 | XPZ-1250 | XPZ-1360 | XPZ-1520 | XPZ-1650 | XPZ-1950 | XPZ-2650 | |
| XPZ-670 | XPZ-825 | XPZ-925 | XPZ-1030 | XPZ-1150 | XPZ-1262 | XPZ-1400 | XPZ-1525 | XPZ-1700 | XPZ-2000 | XPZ-3000 | |
| XPZ-710 | XPZ-830 | XPZ-940 | XPZ-1060 | XPZ-1180 | XPZ-1270 | XPZ-1420 | XPZ-1550 | XPZ-1750 | XPZ-2030 | | |
| XPZ-750 | XPZ-850 | XPZ-950 | XPZ-1080 | XPZ-1200 | XPZ-1280 | XPZ-1450 | XPZ-1560 | XPZ-1800 | XPZ-2160 | | |